



Matsunichi MarquisPad MP977 Plastic Front Panel Replacement

This guide will lead you through the process of replacing the plastic front panel of your device.

Written By: Rachel Servis





TOOLS:


- [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Plastic Front Panel



- Remove the two screws using a PH #00 Phillips head screw driver.

Step 2



- Place the device face down on a flat surface.
 - Insert one of the wide tipped, plastic opening tools into the top of the left speaker slot.
- ⚠ Be sure not to puncture the covering of the speaker.
- Pry the back plate open and slide the tool in a clockwise direction, moving it along the opening between the device and its back plate until you reach the power button.

Step 3




- Insert opening tool into the right speaker slot.
- Pry open the back plate, and slide the tool counter clockwise along the device until you reach the charging port.

Step 4




- Remove the back plate and place it to the side.

Step 5



- Remove the screws holding the metal frame plate in place.
- Remove the metal frame plate from the plastic housing.

Step 6



- Place the metal frame plate and components into the new plastic front panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 06:49:57 PM.

